



General Description

Junckers PRELAK is a water-based, fast drying primer that is to be used in combination with water-based floor finishing products.

Junckers PRELAK provides a water-based solution to priming of floors with wood species sensitive to changes in humidity.

Technical Data

Product:	Water-based acrylic primer.
Package sizes:	10 litres
Appearance:	Creamy/milky. Dries up to a clear film with a lighter appearance than solvent-based primers.
Coverage:	8 m ² per litre.
Application tools:	Short hair mohair roller.
Substrate temperature:	Minimum 15°C.
Dilution:	Delivered ready for use. Dilution is not recommended.
Drying time:	Approx. 1-2 hours at 20°C.
Cleaning of tools:	Soap and water immediately after use. Alcohol after drying.
Storage:	Not to be exposed to temperatures below 0°C. Shelf life 1 year in unopened can and stored at 20°C.
Disposal:	Remains of product should dry up in container and then be removed with other industrial wastes. Do not allow to enter drains.

System Recommendations

High traffic areas:	1 coat Junckers PRELAK 8 m ² /ltr. + 2 coats Junckers STRONG 10m ² ltr.
or	
	1 coat Junckers PREFILL + 1 coat Junckers PRELAK 8 m ² /ltr + 2 coats Junckers STRONG 10 m ² /ltr
Low traffic areas:	1 coat Junckers PRELAK 8 m ² /ltr. + 2 coats Junckers STRONG 8m ² /ltr.
or	
	1 coat Junckers PREFILL + 1 coat Junckers PRELAK 8 m ² /ltr + 1 coats Junckers STRONG 10 m ² /ltr
Sport:	1 coat Junckers PRELAK 8 m ² /ltr. + 2 coats Junckers SPORT High Performance 10 m ² /ltr.
or	
	1 coat Junckers PREFILL + 1 coat Junckers PRELAK 8 m ² /ltr + 1 - 2 coats Junckers SPORT High Performance 10 m ² /ltr.

Directions for Use

Untreated/sanded floors

The surface should be clean, dry and free from dust, wax, grease, polish etc.. Machine sand the surface to remove dirt and irregularities. The last sanding, before applying Junckers PRELAK should be carried out by using minimum grit 120.

Apply Junckers PRELAK as an even coat using a clean, shorthaired roller-applicator. Do not apply by spraying.

When the primer is dry sand with grit 150-180 or a black nylon screening pad.

Previously lacquered floors:

Machine sand before applying Junckers PRELAK. Use grit 24 to strip old coats. Then remove abrasion marks with grit 60. Finally, use grit 120-180 to obtain a completely smooth surface. Vacuum sanding dust and prime the floor as described under "Untreated/ sanded floors".

Important!

Before use of the product, read the label on the container carefully.