



Boen Refresher is a product designed for periodic maintenance of varnished parquet and wooden flooring. The product will freshen up aged and matt varnish, will protect the varnish and provide a glossy and wear resistant finish.

Sealed floors -Boen Refresher

Application:

The floor must be free from polish, wax and other contamination prior to treatment. Apply a thin coat of Boen Refresher using a clean, soft and lint-free cloth or sponge. Boen Refresher must not be thinned with water. Let the floor dry for 30 minutes before replacing furniture and carpets. The use of felt cushions on furniture is recommended to avoid unnecessary wear.

Maintenance:

Flooring treated with Boen Refresher should be kept clean by vacuum cleaning, dry mopping or mopping with a mop or cloth, well wrung in lukewarm water. Boen Cleaner or other neutral detergent may be added to the water used for cleaning. Note that alkaline detergents may remove the Boen Refresher.

In domestic use, re-apply Boen Refresher once or twice a year depending on wear. Re-apply as required on flooring with higher wear. Boen Refresher is also well suited to spot maintenance.

Note:

Unlike flooring treated with other polishes and waxes, flooring treated with Boen Refresher can be re-varnished. Clean the floor with Boen Cleaner, rub down lightly with grade 120 - 150 sanding paper, remove sanding dust and apply new Boen Varnish.

