

General Description

Junckers SYLVA SPORT CLEANER is a universal cleaner for lacquered or oiled wooden sports floors.

Junckers SYLVA SPORT CLEANER does not leave a film on the surface and is therefore ideal for daily or regular cleaning.

Junckers SYLVA SPORT CLEANER is ideal for cleaning sports, and aerobic wooden floors from body fats.

To neutralize Junckers SYLVA SPORT CLEANER and restore friction use Junckers SYLVA NEUTRALIZER.

Technical Data

Product:	Contains: Anionic surfactants 5-15%, Isopropanol >5%, Preservation agent < 1%.
pH Value:	Diluted: Approx. 6 - 8. Undiluted: Approx. 8.5
Package size:	1 ltr. and 2.5 ltr.
Application tool:	Well wrung cloth or mop.
Dilution:	For normal cleaning use 50-200 ml. to 10 litres of water.
Storage:	2 year if unopened and stored at 20°C in sealed original container.
Restrictions for use:	The concentrate must not be used by persons under 18 years of age.

Directions for Use

Weekly Maintenance

To 10 litres of water add 50 - 200 ml of SYLVA SPORT CLEANER. The cleaner is applied using a well wrung cloth. For areas of high wear the floor can be treated more frequently.

Relacquering:

Use Junckers SYLVA NEUTRALIZER to remove remains of SYLVA SPORT CLEANER before re-lacquering.

Sports floors which have been treated with wax or polish will require sanding before re-lacquering.

Important!

Always use a very well wrung cloth to prevent water damage.
Always wipe up spills quickly using a dry cloth to prevent water damage.

Important!

Before use of the product, read the label on the container carefully.